



# AWNING & CASEMENT BUTT HINGE ANCHOR SCREW INSTALLATION

Part Number	Description	Application
312428A	Screw - #9 x 3/4" Quad (FLT SS)	Temporary screw to be replaced in the field
312450A	Screw - #9 x 3/4" Quad (FLT BK)	
296940A	Screw - #8 x 2" Quad (FLT SS)	Field-installed anchor screw for each hinge.
70113A	Screw - #8 x 2" Quad (FLT BK)	

## Anchor Screw Installation Procedure

1. Remove temporary #9 x 3/4" screw (as noted above) from top hole of each hinge on the jamb.
2. Install one #8 x 2" anchor screw (as noted above) into each hinge with either a #2 Phillips or a #2 Robertson screw driver bit

